

Fig #	Part #	Part Name
1	100297	Screw,Crfchs,M4X0.7X25
2	S32030	Washer, Special
3	S32032	Cover,Exhaust
4	S32045	Muffler
5	100260	Screw, Soc. Hd. Cap M4 X 20
6	S32186	Washer, Special
7	T32010	Cap With Insert
8	S32011	Insert,M4
9	T32007	Bumper, Piston Stop
10	T32028	Spring,Head Valve
11	108572	O-Ring,26Mmx2Mm
12	9R198720	Head Valve
13	108573	O-Ring,1.378X.079
14	S32109	Ring,Piston
15	S32084A	Assembly,Driver/Piston

Fig #	Part #	Part Name
16	T32031	Seal,Cylinder Sleeve
17	S32208	Sleeve,Cylinder
18	RG161210	O-Ring,1.612X.103 Nbr
19	T32080	Check Seal
20	100353	O-Ring,1.301X.070
21	102882	Bumper
22	S32187	Plate, Frame
23	S32001	Washer, Urethane Orange
24	S32088	Guide,Driver
25	T32046	Gasket,Frame/Cap
26	T32008A	Frame
27	113218	Label,Bostitch
28	106173	Stop,Trigger
29	100298	Pin,Spiral M3X30
30	102549	Pin,Special Spirol M3Xm25

Fig #	Part #	Part Name
31	S32141	Gasket, End Cap
32	S32140	Cap,End
33	S32017A	Assembly,Nut Plate
34	T32106	Nose
35	S32182	Cover,Nose
36	S32184	Spacer
37	100258	Screw,Shcs,M4X0.7X35

38	S32121	Guard,Arm
39	MHE4070-100	Elastic Stop Nut,M4
40	S32122A	Assembly,Arm Guide
41	S32120	Arm,Lower Contact
42	S32127	Arm,Upper Contact
43	110071	Pin,Spring,M2X10Mm
44	100364	Screw,Sfhcs,M4X0.7X14
45	S32066	Pin,Special

Fig #	Part #	Part Name
46	S32072	Plate,Spring
47	S32009	Latch Magazine
48	T27160	Spring,Compression
49	S32024	Spring,Compression
50	S32025	Handle,Latch
51	S32082	Magazine
52	S32096	Pusher
53	S32177	Stop,Core
54	MSC4070-8	Screw,Shcs,M4X0.70X8
55	S32065	Spring,Pusher
56	S32061A	Assembly,Spring Rod
57	S32100	Support,Rod
58	S32078A	Assembly,Core Slide
59	S32063	End,Core
60	S32178	Washer,Pusher Spring

Fig #	Part #	Part Name
62	100263	Pin,Spirol,M4X14Mm
63	100264	Pin,Spirol,.1875X.500
64	159911	Label-Warning
65	159914	Label-Warning
66	TVA5	Kit,S32/Bt Trigger Vlv
67	86459	O-Ring,.614X.070
68	106967	O-Ring,.724X.106
69	CNTK2	Kit,Contact Trip Conversion
70	SEQ6	Kit,Sequential
71	DTK1	Kit,Dual Trigger
72	100817	O-Ring,1.299X.103
73	S32211	Ring,Cylinder Sleeve
74	105235	Screw,Shcs M4X25