


HN90 (New)



HN90 (CE) - Parts List

Part No.	Part Code	Description
1	HS10704	SCREW 6X38
2	HN70097	CYLINDER CAP UNIT
3	HN10773	CYLINDER CAP SEAL
4	KK23650	COMP SPRING 3650
5	HN10774	PISTON STOP
6	HH19719	O-RING 1A2.6X54.5
7	HH11157	O-RING ARP568-136 850006
8	HN10776	HEAD VALVE PISTON
9	HN10777	HEAD VALVE GUIEDE
10	HH14729	O-RING AS568-144
11	HH11806	O-RING P27
12	HN70087	MAIN PISTON UNIT
13	HN10780	CYLINDER SEAL
14	HH19200	O-RING 1A 2.6 X 52.5 <<<<<
15	HH11109	O-RING 1AP40 <<<<<
16	HN10778	CYLINDER A
17	HH19196	O-RING 1A 4.9X43 851439
18	HN10779	CYLINDER B
19	HN10807	BUMPER
20	HN81061	EXHAUST COVER UNIT
21	HS10078	FILTER B
22	HS10077	FILTER A
23	HN81062	FRAME UNIT
24	CN34309	PLASTIC SHEET LABEL (100421)
25	HN10810	NAME LABEL A
26	HN10811	NAME LABEL B
27	KK23507	SPRING 3507
28	CN35074	TRIGGER LOCK DIAL
29	FF21235	SPRING PIN 3X30
30	HH11120	O-RING ARP568-009 CN65079
31	HN10775	PIPE
32	HH19127	O-RING A 1.5X5.5
33	HN10379	GRIP COVER
34	CN35075	TRIGGER LOCK LEVER
35	HN10857	PROTECTOR M
36	TA17024	FILTER A
37	HH19102	O-RING 1A 2.4X31.8 T29011(REPLACES TA15265)
38	HN10517	END CAP
39	HN10316	END PLUG CAP
40	TT05425	AIR PLUG H-FPM
41	HN10017	PILOT VALVE
42	BB40470	SCREW 5X32
43	HN10019	TRIGGER VALVE CAP
44	HN10820	FEED NOZZLE
45	HH19722	O-RING A1.5X5
46	HN10043	PILOT CAP
47	HN10018	PILOT SEAL
48	HN12105	O-RING 1A 1.5X12.8
49	HN10016	TRIGGER VALVE HOUSING
50	HN10353	TRIGGER VALVE STEM
51	HH11804	O-RING P6
52	HS10139	PILOT VALVE
53	HH11132	O-RING 1AP10A CN65072
54	KK23906	COMPRESSION SPRING 3906
55	KK23619	COMP. SPRING 3619
56	HH19707	O-RING A1.4X2.5
57	HS10141	TRIGGER VALVE STEM

58	HH19214	O-RING 1B 1.5X3
59	HS10140	TRIGGER VALVE CAP
60	HN10100	CONTACT LVER
61	HS10144	CONTACT LEVER B
62	HS10143	CONTACT LEVER A
63	HS10147	TRIGGER
64	FF22402	SPRING PIN 3X16 (LIGHT LOAD)
65	HN10786	ARM GUIDE PLATE
66	KK33300	SPRING 3300
67	HS10146	SWITCH LEVER B
68	CN34500	SPRING, LEVER
69	KK23735	COMPRESSION SPRING 3735
70	KK23736	COMPRESSION SPRING 3736
71	KK23129	COMPRESSION SPRING 3129
72	HN10784	ARM GUIDE
73	HN10785	CONTACT BUMPER
74	HN10818	CONTACT ARM A
75	HN10026	ADJUST DIAL
76	HN10787	ADJUST APACER
77	HH14734	O-RING AS568-031
78	HN10794	NOZE
79	EE39602	WASHER 7
80	BB40224	SCREW 7X25
81	CN33679	DOOR LATCH
82	KK33353	TORSION SPRING 3353
83	FF41599	PIN 1599 (REPLACES FF41587)
84	HN10796	DOOR
85	FF41817	STEP PIN 1817
86	HN10797	RATCHET
87	KK23912	COMPRESSION SPRING 3912
88	EE39609	RUBBER WASHER 1.8X6X2
89	FF31520	STRAIGHT PIN 1520
90	BB40460	BOLT 5 X 28
91	HN10790	CONTACT BOLT
92	HH11903	O-RING 1A 1.2 X 4 T29051(REPLACES TA15277)
93	KK23901	COMPRESSION SPRING 3901
94	HN70091	CONTACT ARM B UNIT
95	JJ10404	E-RING 3.2
96	HN10817	CONTACT TIP
97	FF31294	PARALLEL PIN 1294
98	CN35336	CHECK PAWL
99	KK33337	TORSION SPRING 3337
100	HN10795	FEED PAWL (USA)
101	KK23710	COMP. SPRING 3710
102	KK23788	COMP. SPRING 3788
103	FF42216	STEP PIN 2216
104	HN10808	ARM COVER
105	CC00401	ELASTIC STOP NUT M5
106	HH11111	O-RING 1AP 14 N5522(REPLACES TA15260)
107	HN10463	FEED PISTON
108	HH11107	O-RING AP18
109	KK23926	COMP.SPRING 3926
110	KK23927	COMPRESSION SPRING 3927
111	CN31570	FEED PISTON STOP
112	HN10464	COMP. SPRING
113	JJ22407	C-RING 26
114	CN30602	SPRING HOOK
115	KK13144	SPRING 3144 (SUPERCEDES KK13040)
116	CN30601	SPACER CN65091
117	FF41287	PIN 1287
118	HN10822	MAGAZINE
119	HN10357	CONTACT BUMPER
120	HN10478	NAIL SUPPORT
121	CN31963	POST CAP

122	HN10400	ARM GUIDE PIN
123	HN10401	CONTACT ARM A
124	HN10853	MAGAZINE CAP
125	HS10118	TRIGGER
126	HS10117	CONTACT ARM A GUIDE
127	HN10851	WARNING LABEL
128	HN81072	MAGAZINE CAP ASSY
129	HN81043	MAGAZINE ASSY
130	HN10809	DUST COVER
131	BB40427	T-BOLT 4 X 8(REPLACES TA15544)
132	EE39172	WASHER 5.1X12X1.2
133	CN31083	HOOK, DUST COVER
134	HN10145	SWITCH LEVER A
135	HN10067	SCREW 6 X35
144	HN10856	FRAME HANGER
145	HN10783	PROTECTOR
146	HN10819	EXHAUST COVER
147	TA81014	STEP PIN KIT
148	EE39609	RUBBER WASHER 1.8X6X2
149	FF41842	PIN 1842
200	HN81068	ARM GUIDE KIT
201	HS80007	TRIGGER VALVE KIT
202	HN81069	DS KIT
203	HN81070	O-RING KIT
204	HN81071	FRAME HANGER KIT